


# The right cartridge for your printer



Printer Model	70	75	80	85	19	20	25	90	48	50	60	13400HC	13619HC	1382050	1382060	15M0640	10N0016	10N0026	10N0217	10N0227	82	83	88	
<b>Lexmark</b>																								
Color Jetprinter 3200, 5000, 5700, 5770, 7000, 7200, 7200 V, OptraColor 40&45, Z31	●	●	●	●				●																
Lexmark Z11 Color Jetprinter	●	●	●	●																				
Lexmark Z12 Color Jetprinter										●	●													
Lexmark Z13 <sup>1</sup> , Z23e <sup>1</sup> , Z24, Z25, Z25i, Z33 <sup>1</sup> , Z34, Z35 Color Jetprinter, i3 <sup>2</sup> , AIO X72, X74, X75, <b>NEW</b> AIO X1100 Series, Z600 Series																	●	●	●	●				
Lexmark Z22, Z32 Color Jetprinter								●		●	●													
Lexmark Z42, Z43, Z44, Z45, Z45se, Z51, Z52, Z53, Z54, Z54se Color Jetprinter, AIO X125,	●	●					●	●	●															
Color Jetprinter 1000, 1020, 1100, 2030, 2050, 2055, 3000, Execjet Iic, Winwriter 150c, Medlay 4c, 4x, 4sx												●	●											
Execjet II, WinWriter 100												●												
Lexmark Color Jetprinter 2070														●	●									
Lexmark AIO X63, X70, X73, X80, X83, X84, X85, <b>NEW</b> Z700 Series, P700 Series	●	●					●	●	●	●	●													
Lexmark Color Jetprinter Z55, Z55se, Z65, Z65n, Z65p, AIO X5100 Series, AIO X6100 Series																					●	●	●	
<b>Samsung</b>																								
Smartjet, SF4500 Series, Msys4700, Msys4800, MJ4500C	●	●	●	●				●																
SF3150	●	●																						
SF4700 Series, SCX1000 Series, SCX1100, SCX1150, SF4300	●	●					●	●	●															
SCX1050F, SF4750C							●	●																
SF3100P, SF4100, SF4120, SF4200, SF4220												●	●											
SF3000, SF3000T, SF3100, SF3100P, SF3100T, SF3200, SF4000, SF4020												●	●											
SF3000, SF3000T, SF3100, SF3100P, SF3100T, SF3200, S4000, SF4020, SF4100, SF4120, SF4200, SF4220																	●							
<b>Kodak</b>																								
Personal Picture Maker PM100	●	●	●	●																				
<b>Compaq</b>																								
IJ650 Series																	●	●						
A900 <sup>3</sup> , C3-1000, IJ300, IJ700 <sup>3</sup> , IJ750, IJ900 <sup>3</sup>	●	●	●	●				●																
A1000, A1500, A3000, A4000, IJ1200, 1400P	●	●					●	●	●															
IJ600								●		●														
IJ200												●	●											

<sup>1</sup> New drivers need to be downloaded from Lexmark website to accept moderate use cartridges. <sup>2</sup> New driver not available for i3. <sup>3</sup> A900 driver does not recognize the high yield black cartridge ; IJ700 and IJ900 drivers do not recognize high yield black and color cartridges. <sup>4</sup> Delivered with a storage unit.