





## Papers and Transparencies for Lexmark Page Printers

Part Number	A4 Glossy Paper Box of 200	A4 Transparencies Box of 50					
	12A5951	12A5941	12A5591	1053741	12A0541	1402741	12A5010
<b>Lexmark</b>							
C720	•		•				
C750	•	•					
C910	•	•					
E210							•
E320/ E322							•
T520/ T522/ T620/ T622				•			
W820							•
Optra C710	•	•					
Optra C	•					•	
Optra Color 1200	•	•			•		
Optra E310/ E312/ E312L							•
Optra E							•
Optra K 1220							•
Optra M410/ M412							•
Optra N				•			
Optra S				•			
Optra Se 3455				•			
Optra SC 1275	•			•			
Optra T/ T610/ T612/ T614/ T616				•			
Optra W810							•
4019, 4028, 4029, 4027-4W, 4037-5E, 4039, 4047-5E, 4047-5W, ValueWriter 300/ 400/ 600, WinWriter 200/ 400/ 600 4039 10+, 4049, Optra L/ R series				•			•
<b>Hewlett-Packard</b>							
LaserJet 4500/ 4550 series		•					
LaserJet 8500/ 8550 series		•					

## Lexmark Matrix Printer Supplies

Description	Ribbons			
	General Purpose Ribbon 1040864	General Purpose Ribbon 13L0034	23XX/ 24XX Black Re-inking Ribbon 11A3540	24XX High Yield Black Re-inking Ribbon 11A3550
<b>Lexmark</b>				
4226	•			
4227/ 4227 Plus		•		
2480/ 81, 2490/ 91, 2380/ 81, 2390/ 91 & 2380+			•	
2480/ 81, 2490/ 91			•	•



*A new cartridge,  
a new print head...  
like a brand new  
printer !*

## Lexmark Ink Jet Printer Supplies

Lexmark	Cartridges										
	Description	High Resolution Standard Black	High Resolution Standard Colour Cyan/Magenta/Yellow	High Resolution High Yield Black	High Resolution High Yield Colour Cyan/Magenta/Yellow	3 Pack High Resolution High Yield Black	3 Pack High Resolution High Yield Colour	Black Moderate Use	Colour Moderate Use	High Resolution Photo Colour	PerfectFinish™ Cartridge
ColorJetprinter™ Z55/ Z65/ Z65n <b>New</b>	18L0032	18L0042		18L0000							
ColorJetprinter Z25/ Z35 <b>New</b>	10N0016	10N0026						10N0217	10N0227		
X63/ X73/ X83 All-In-One Products	12A1970	15M0120	12A1975	15M0125	15M0100			15M0375			
ColorJetprinter I3**/ Z13*/ Z23e*/ Z33*	10N0016	10N0026						10N0217	10N0227		
ColorJetprinter Z43/ Z45/ Z53	12A1970	15M0120	12A1975	15M0125	15M0100			15M0375		12A1990	
ColorJetprinter Z42/ Z51/ Z52	12A1970	15M0120	12A1975	15M0125	15M0100			15M0375		12A1990	
ColorJetprinter Z31	12A1970	12A1980	12A1975	12A1985	15M0100			15M0101		12A1990	
ColorJetprinter Z22/ Z32	17G0050	17G0060								12A1990	
ColorJetprinter Z11	12A1970	12A1980	12A1975	12A1985	15M0100			15M0101		12A1990	
ColorJetprinter Z12	17G0050	17G0060								12A1990	
ColorJetprinter 3200/ 5000/ 5700/ 5770/ 7000/ 7200	12A1970	12A1980	12A1975	12A1985	15M0100			15M0101		12A1990	
ColorJetprinter 3000/ 2055/ 2050/ 2030/ 1100/ 1020/ 1000	13400HC	13619HC									
J110	11J3020	11J3021C / 11J3022M 11J3023Y			11J4001	11J4002C / 11J4003M 11J4004Y					11J3050
Optra Color 40/ 45	12A1970	12A1980	12A1975	12A1985	15M0100					12A1990	
ExecJet™ II 4076/ WinWriter 100	13400HC										
ExecJet II C/ WinWriter 150c	13400HC	13619HC									
4079	1380490	1380491C / 1380492M 1380493Y									
4072	1380479										
4070	1380630										
<b>Samsung</b>											
Smartjet, SF4500 Series, Msys4700, Msys4800, MJ4500C	12A1970	12A1980	12A1975	12A1985						12A1990	
SF3150	12A1970		12A1975								
SCX1100, SCX1150, SCX4300	12A1970		12A1975								
SF4700 Series, SCX1000 Series	12A1970	15M0120	12A1975	15M0125						12A1990	
SF3000 Series, SF3100 Series, SF4000 Series	13400HC										
SF3100P, SF4100 Series, SF4200 Series	13400HC	13619HC									
<b>Compaq</b>											
Compaq A1000, LJ1200	12A1970	15M0120	12A1975	15M0125						12A1990	
Compaq A900, C3-1000, LJ300, LJ700, LJ750, LJ900	12A1970	12A1980	12A1975	12A1985						12A1990	
Compaq LJ650	10N0016	10N0026									
Compaq LJ600	17G0050	17G0060								12A1990	
Compaq LJ200	13400HC	13619HC									
<b>Kodak</b>											
Kodak Personal Picture, Maker PM100	12A1970	12A1980	12A1975	12A1985							

\* New drivers need to be downloaded from Lexmark website to accept moderate use cartridges.

\*\* New driver not available for i3.

Lexmark	Other Supplies				Papers & Transparencies		
	Description	Print Head Kit with Cartridges	Fax / MFP Black	A4 High Res. Premium Paper 1402781	A3 / A3+ High Res. Coated Paper 12A0851 12A0852	A4 / A3 Coated Paper 1372081 1372082	A4 Transparency 12A5412
J110	11J3000 (black) 11J3010 (colour)			•			•
X63/ X73/ X83 All-In-One Products				•			•
Color Jetprinter I3/ Z65/ Z65n/ Z55/ Z53 Z52/ Z51/ Z45/ Z43/ Z42/ Z35/ Z33/ Z32 Z31/ Z25/ Z23e/ Z22/ Z13/ Z12/ Z11				•			•
ColorJetprinter 3200/ 5000/ 5700/ 5770/ 7000/ 7200				•			•
ColorJetprinter 3000/ 2055/ 2050/ 2030/ 1100/ 1020/ 1000				•			•
Optra Color 40/ 45				•	•		•
ExecJet II 4076/ WinWriter 100				•			•
ExecJet II C/ WinWriter 150c				•			•
4079				•		•	•
4072				•		•	•
4070				•			•
<b>Samsung</b>							
SF3000 Series, SF3100 Series, SF4000 Series			15M0640				
SF3100P, SF4100 Series, SF4200 Series			15M0640				



*The right choice !*

## Lexmark Linea™ Print Cartridges

	Part Number	140196A <span style="color: red;">New</span>	140127T/ X/ A	140198T/ X/ A/ P/ S	140109T/ A	140100A	140191A	140195A
Model	Printer Engine	EP-32	52X	EX	WX	BX	NX	SX
<b>Apple</b>								
LaserWriter II F/ II G/ IINT/ IISC								•
LaserWriter I NTX/ II NTX/ IISX								•
LaserWriter Pro 600/ 630				•				
LaserWriter 16/ 600 PS				•				
<b>Brother</b>								
HL 8/ 8E/ 8J/ 8II/ 8D/ 8PS								•
HL 8J/ 8PSAP/ 8V								•
HL10/ 10DV/ 10PS/ 10V/ 10H								•
HL 8PSJ						•		
HL1260/ 1660/ DX/ E/ NE/ NTR/ PS				•		•		
Calcomp - CCL1200 ES/ 600 - ES - XF						•		
<b>Canon</b>								
LBP 2460					•			
LBP B 406G						•		
LBP 200V/ 8 II/ 8 II F/ 8 II R								•
LBP 8 II SX/ 8 II T/ 8 III/ 8III R								•
LBP 8 III Plus/ 8 III T/ RX/ SX/ TX								•
LBP 8 IV/ 8 Mark IV/ EX/ P270				•				
LBP 860/ 1260				•				
LBP NX/ NX600							•	
LBP BXII						•		
LBP 1000/ EP-32	•							
LBP 1760/ 1760E/ 1760NE/ 1760TNE/ 52X			•					
<b>DEC</b>								
Printserver 17/ 600							•	
DECLaser 2100/ 2150								•
DECLaser 2200/ 2250								•
LN 05/ LN 06								•
DECLaser 5100				•				
<b>GENICOM</b>								
6100 Series/ 6145								•
9170							•	
9080						•		
<b>Hewlett-Packard</b>								
LaserJet Series II/ IID/ III/ IIID								•
LaserJet 4/ 4M/ 4+/ 4M+				•				
LaserJet 5/ 5M/ 5N				•				
LaserJet 4V/ 4MV						•		
LaserJet III Si/ 4Si/ 4Si MX							•	
LaserJet 2100/ 2100SE/ 2100XI/ 2100M/ 2100TN	•							
LaserJet 2200/ 2200D/ 2200DT/ 2200DN/ 2200DTN	•							
LaserJet 4000/ 4000N/ 4000T/ 4000TN			•					
LaserJet 4050/ 4050N/ 4050T/ 4050TN			•					
LaserJet 5Si/ 5Si MX/ 5Si NX/ 5Si Mopier					•			
LaserJet 8000/ 8000N/ 8000DN					•			
<b>Lexmark - Opra N</b>								
OCE - 6450/ 6451						•		
Olivetti - PG 108								•
<b>QMS</b>								
1725/ SLS/ E Print Systems							•	
2308 S/ 3308S/ Kiss Plus								•
Lasergraphix 810/ 820								•
PS 810/ 810II/ 810 Turbo								•
PS 815/ 820/ 820 Turbo/ 825								•
Turbo Imageserver XP								•
860 Plus/ 1660 Plus						•		
2425					•			